



S-Class Coupe

Operator's Manual

S-Class Coupe Operator's Manual



2175840301

Order no. 6515 4519 13 Part no. 217 584 03 01 Edition C 2015



Mercedes-Benz

Symbols

Registered trademarks:

- Bluetooth® is a registered trademark of Bluetooth SIG Inc.
- DTS is a registered trademark of DTS, Inc.
- Dolby and MLP are registered trademarks of DOLBY Laboratories.
- BabySmart™, ESP® and PRE-SAFE® are registered trademarks of Daimler AG.
- HomeLink® is a registered trademark of Johnson Controls.
- iPod® and iTunes® are registered trademarks of Apple Inc.
- Burmester® is a registered trademark of Burmester Audiosysteme GmbH.
- Microsoft® and Windows media® are registered trademarks of Microsoft Corporation.
- SIRIUS is a registered trademark of Sirius XM Radio Inc.
- HD Radio is a registered trademark of iBiquity Digital Corporation.
- Gracenote® is a registered trademark of Gracenote, Inc.
- ZAGATSurvey® and related brands are registered trademarks of ZagatSurvey, LLC.


In this Operator's Manual you will find the following symbols:


WARNING

Warning notes make you aware of dangers which could pose a threat to your health or life, or to the health and life of others.

Environmental note

Environmental notes provide you with information on environmentally aware actions or disposal.

 Notes on material damage alert you to dangers that could lead to damage to your vehicle.

 Practical tips or further information that could be helpful to you.

▶ This symbol indicates an instruction that must be followed.

▶ Several of these symbols in succession indicate an instruction with several steps.

(▷ This symbol tells you where you can find more information about a topic.

▷▷ This symbol indicates a warning or an instruction that is continued on the next page.

Dis- This text indicates a message in the multifunction/COMAND/Audio display.

Parts of the software in the vehicle are protected by copyright © 2005 The FreeType Project <http://www.freetype.org>. All rights reserved.

Publication details

Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

<http://www.mbusa.com> (USA only)

<http://www.mercedes-benz.ca> (Canada only)

Editorial office

©Daimler AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Daimler AG.

Vehicle manufacturer

Daimler AG
Mercedesstraße 137
70327 Stuttgart
Germany

Welcome to the world of Mercedes-Benz

We urge you to read this Operator's Manual carefully and familiarize yourself with the vehicle before driving. For your own safety and a longer vehicle life, follow the instructions and warning notices in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others.

Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

The equipment or product designation of your vehicle may vary depending on:

- model
- order
- country specification
- availability

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- design
- equipment
- technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The following are integral components of the vehicle:

- Operator's Manual
- Maintenance Booklet
- Equipment-dependent supplements

Keep these documents in the vehicle at all times. If you sell the vehicle, always pass all documents on to the new owner.

The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company

Index	4	At a glance	29
Introduction	21	Safety	41
		Opening and closing	77
		Seats, steering wheel and mirrors ..	101
		Lights and windshield wipers	119
		Climate control	131
		Driving and parking	145
		On-board computer and displays	225
		Stowage and features	293
		Maintenance and care	317
		Roadside Assistance	335
		Wheels and tires	355
		Technical data	389

1, 2, 3 ...

4ETS

see ETS/4ETS (Electronic Trac-
tion System)

4MATIC (permanent four-wheel

drive) 194

12 V socket

see Sockets

360° camera

Cleaning 330

Function/notes 207

A**ABS (Anti-lock Braking System)**

Display message 247

Function/notes 66

Important safety notes 66

Warning lamp 281

Accident

Automatic measures after an acci-
dent 60

Activating/deactivating cooling

with air dehumidification 134

Activating/deactivating Night**View Assist Plus**

With spotlight function 215

Active Blind Spot Assist

Activating/deactivating (on-
board computer) 241

Display message 269

Function/information 217

Active Body Control (ABC)

Display message 267

Function/notes 190

Active Lane Keeping Assist

Activating/deactivating (on-
board computer) 242

Display message 268

Function/information 220

Active multicontour seat 107

Active Parking Assist

Detecting parking spaces 199

Display message 269

Exiting a parking space 201

Function/notes 198

Important safety notes 198

Parking 200

ADAPTIVE BRAKE 73

Adaptive Brake Assist

Function/notes 70

Adaptive Damping System (ADS) 193

Adaptive Highbeam Assist Plus

Display message 263

Function/notes 123

Switching on/off 124

Additional speedometer 244

Additives (engine oil) 394

Air bags

Deployment 57

Display message 259

Front air bag (driver, front
passenger) 50

Important safety notes 48

Introduction 48

Knee bag 50

PASSENGER AIR BAG indicator

lamps 43

Side impact air bag 50

Window curtain air bag 51

Air vents

Glove box 143

Important safety notes 142

Rear 143

Setting 142

Setting the center air vents 142

Setting the side air vents 143

Air-conditioning system

see Climate control

AIRMATIC

Display message 266

Function/notes 192

Alarm

ATA (Anti-Theft Alarm system) 76

Switching off (ATA) 76

Switching the function on/off
(ATA) 76

Alarm system

see ATA (Anti-Theft Alarm system)

Anti-lock braking system

see ABS (Anti-lock Braking System)

Anti-Theft Alarm system

see ATA (Anti-Theft Alarm system)

Armrest

Stowage compartment 296

- Ashtray** 300
- Assistance display (on-board computer)** 239
- Assistance menu (on-board computer)** 240
- ASSYST PLUS**
- Displaying a service message 324
 - Hiding a service message 324
 - Notes 324
 - Resetting the service interval display 324
 - Service message 324
 - Special service requirements 325
- ATA (Anti-Theft Alarm system)**
- Activating/deactivating 76
 - Function 76
 - Switching off the alarm 76
- ATTENTION ASSIST**
- Activating/deactivating 241
 - Display message 266
 - Function/notes 211
- Authorized Mercedes-Benz Center**
see Qualified specialist workshop
- Authorized workshop**
see Qualified specialist workshop
- AUTO lights**
- Display message 262
 - see Lights
- Automatic car wash (care)** 325
- Automatic engine start (ECO start/stop function)** 152
- Automatic engine switch-off (ECO start/stop function)** 151
- Automatic headlamp mode** 120
- Automatic transmission**
- Accelerator pedal position 158
 - Automatic drive program 159
 - Changing gear 158
 - DIRECT SELECT lever 155
 - Display message 275
 - Driving tips 158
 - Emergency running mode 163
 - Engaging drive position 156
 - Engaging neutral 156
 - Engaging park position automatically 155
 - Engaging reverse gear 155
 - Engaging the park position 155
 - Kickdown 158
 - Manual drive program 160
 - Manual drive program (AMG vehicles) 161
 - Overview 155
 - Problem (malfunction) 163
 - Program selector button 158
 - Pulling away 150
 - Starting the engine 150
 - Steering wheel paddle shifters 159
 - Transmission position display 157
 - Transmission positions 157
- Automatic transmission emergency mode** 163
- B**
- BAS (Brake Assist System)** 66
- BAS PLUS Q (Brake Assist System PLUS) with Cross-Traffic Assist**
- Function/notes 67
 - Important safety notes 67
- Battery (SmartKey)**
- Checking 82
 - Important safety notes 81
 - Replacing 82
- Battery (vehicle)**
- Charging 343
 - Display message 264
 - Important safety notes 341
 - Jump starting 345
- Belt**
see Seat belts
- Blind Spot Assist**
see Active Blind Spot Assist
- Brake Assist**
see BAS (Brake Assist System)
- Brake fluid**
- Display message 254
 - Notes 394
- Brake force distribution, electronic**
see EBD (electronic brake force distribution)
- Brake lamps**
- Display message 261

Brakes

ABS	66
Adaptive Brake Assist	70
BAS	66
BAS PLUS with Cross-Traffic Assist	67
Brake fluid (notes)	394
Display message	247
EBD	73
High-performance brake system	173
Hill start assist	150
HOLD function	188
Important safety notes	172
Maintenance	172
Parking brake	168
Riding tips	172
Warning lamp	280

Breakdown

- see Flat tire
- see Towing away

Brightness control (instrument cluster lighting)

33

Buttons on the steering wheel

227

C**California**

Important notice for retail customers and lessees	23
---	----

Calling up a malfunction

- see Display messages

Camera

- see 360° camera

Car

- see Vehicle

Car key

- see SmartKey

Care

360° camera	330
Car wash	325
Carpets	333
Display	331
Exhaust pipe	331
Exterior lights	329
Gear or selector lever	332
Interior	331
Matte finish	328
Night View Assist Plus	331

Notes	325
Paint	327
Plastic trim	332
Power washer	327
Rear view camera	330
Roof lining	333
Seat belt	333
Seat cover	332
Sensors	329
Steering wheel	332
Trim pieces	332
Washing by hand	327
Wheels	328
Windows	329
Wiper blades	329
Wooden trim	332

CD player/CD changer (on-board

computer)

236

Center console

Overview	35
Stowage space	295

Center console in the rear compartment

Stowage compartment	297
---------------------------	-----

Central locking

Locking/unlocking (SmartKey)	79
------------------------------------	----

Child

Restraint system	62
------------------------	----

Child seat

Forward-facing restraint system	65
LATCH-type (ISOFIX) child seat anchors	63
On the front-passenger seat	64
Rearward-facing restraint system	64
Top Tether	63

Children

In the vehicle	60
Special seat belt retractor	61

Cigarette lighter

300

Cleaning

Mirror turn signal	329
--------------------------	-----

Climate control

Automatic climate control	133
Controlling automatically	135
Cooling with air dehumidification ..	134
Defrosting the windows	137
Defrosting the windshield	137
ECO start/stop function	133

- General notes 132
- Indicator lamp 135
- Ionization 142
- Notes on using the automatic climate control 133
- Overview of systems 132
- Perfume atomizer 140
- Problem with the rear window defroster 139
- Problems with cooling with air dehumidification 135
- Refrigerant 396
- Refrigerant filling capacity 396
- Setting the air distribution 136
- Setting the air vents 142
- Setting the airflow 137
- Setting the climate mode 136
- Setting the temperature 136
- Switching air-recirculation mode on/off 139
- Switching on/off 134
- Switching residual heat on/off 139
- Switching the rear window defroster on/off 138
- Switching the synchronization function on and off 137
- Climate control system**
- Automatic engine start 152
- Automatic engine switch-off 151
- Climate control 134
- Deactivating/activating 152
- Important safety notes 151
- Introduction 151
- Cockpit**
- Overview 30
- COLLISION PREVENTION ASSIST PLUS**
- Activating/deactivating 240
- Display message 255
- Operation/notes 68
- COMAND display**
- Cleaning 331
- Combination switch** 122
- Consumption statistics (on-board computer)** 232
- Convenience closing feature** 95
- Convenience opening feature** 95
- Coolant (engine)**
- Checking the level 322
- Display message 263
- Filling capacity 395
- Important safety notes 395
- Temperature gauge 226
- Warning lamp 287
- Coolbox** 302
- Cooling**
- see Climate control
- Copyright** 28
- Cornering light function**
- Display message 260
- Function/notes 123
- Crash-responsive emergency lighting** 126
- Crosswind Assist (vehicles with MAGIC BODY CONTROL)** 190
- Crosswind Assist (vehicles without MAGIC BODY CONTROL)** 72
- Cruise control**
- Cruise control lever 176
- Deactivating 177
- Display message 272
- Driving system 175
- Function/notes 175
- Important safety notes 175
- Setting a speed 177
- Storing and maintaining current speed 176
- Cup holder**
- Center console 298
- Important safety notes 298
- Rear compartment 299
- Customer Assistance Center (CAC)** 26
- Customer Relations Department** 26
- D**
- Data**
- see Technical data
- Daytime running lamps**
- Display message 262
- Function/notes 120
- Switching on/off (on-board computer) 243
- Declarations of conformity** 25

- Diagnostics connection** 25
- Digital speedometer** 232
- DIRECT SELECT lever**
 - Automatic transmission 155
- Display**
 - see Display messages
 - see Warning and indicator lamps
- Display messages**
 - ASSYST PLUS 324
 - Calling up (on-board computer) 246
 - Driving systems 266
 - Engine 263
 - General notes 246
 - Hiding (on-board computer) 246
 - Introduction 246
 - Lights 260
 - Safety systems 247
 - SmartKey 277
 - Tires 273
 - Vehicle 275
- Distance recorder**
 - see Odometer
 - see Trip odometer
- Distance warning (warning lamp)** 289
- Distance warning function**
 - Function/notes 69
- DISTRONIC PLUS**
 - Activating 179
 - Activation conditions 179
 - Cruise control lever 179
 - Deactivating 184
 - Display message 271
 - Displays in the multifunction display 183
 - Driving tips 184
 - Function/notes 177
 - Important safety notes 178
 - Setting the specified minimum distance 182
- Doors**
 - Automatic locking (switch) 86
 - Central locking/unlocking (SmartKey) 79
 - Control panel 38
 - Display message 276
 - Emergency locking 87
 - Emergency unlocking 86
 - Important safety notes 85
 - Opening (from inside) 85
 - Power closing 86
- Drinking and driving** 170
- Drive program**
 - Automatic 159
 - Manual 160
 - Manual (AMG vehicles) 161
 - SETUP (on-board computer) 245
- Driver's door**
 - see Doors
- Driver's/front-passenger seat**
 - Stowage compartment 296
- Driving abroad**
 - Mercedes-Benz Service 325
 - Symmetrical low beam 120
- Driving Assistance package** 217
- Driving safety systems**
 - ABS (Anti-lock Braking System) 66
 - ADAPTIVE BRAKE 73
 - Adaptive Brake Assist 70
 - BAS (Brake Assist System) 66
 - BAS PLUS with Cross-Traffic Assist 67
 - COLLISION PREVENTION ASSIST PLUS 68
 - Distance warning function 69
 - EBD (electronic brake force distribution) 73
 - ESP® (Electronic Stability Program) 71
 - ETS/4ETS (Electronic Traction System) 71
 - Important safety information 65
 - Overview 65
 - PRE-SAFE® Brake 73
 - STEER CONTROL 75
- Driving systems**
 - 360° camera 207
 - Active Blind Spot Assist 217
 - Active Body Control ABC 190
 - Active Lane Keeping Assist 220
 - Active Parking Assist 198
 - AIRMATIC 192
 - ATTENTION ASSIST 211
 - Cruise control 175
 - Display message 266
 - DISTRONIC PLUS 177

DISTRONIC PLUS with Steering Assist and Stop&Go Pilot	186	ECO start/stop function	General information	151
Driving Assistance package	217	Electronic Stability Program	see ESP® (Electronic Stability Program)	
HOLD function	188	Emergency	Automatic measures after an accident	60
Night View Assist Plus	213	Emergency release	Driver's door	86
PARKTRONIC	195	Trunk	93	
Rear view camera	203	Vehicle	86	
Driving tips		Emergency Tensioning Devices	Activation	57
AMG ceramic brakes	173	Emissions control	Service and warranty information	22
Automatic transmission	158	Engine	Check Engine warning lamp	286
Brakes	172	Display message	263	
Break-in period	146	ECO start/stop function	151	
DISTRONIC PLUS	184	Engine number	391	
Downhill gradient	172	Irregular running	154	
Drinking and driving	170	Jump-starting	345	
Driving abroad	120	Starting problems	154	
Driving in winter	174	Starting the engine with the SmartKey	150	
Driving on flooded roads	174	Starting with the Start/Stop button	150	
Driving on wet roads	174	Switching off	167	
Exhaust check	170	Switching off with the Start/Stop button	167	
Fuel	170	Switching off with the vehicle key ..	167	
General	170	Tow-starting (vehicle)	350	
Hydroplaning	174	Engine electronics	Problem (malfunction)	154
Icy road surfaces	174	Engine emergency stop	353	
Limited braking efficiency on salted roads	172	Engine oil	Adding	321
Snow chains	359	Additives	394	
Symmetrical low beam	120	Checking the oil level	319	
The first 1000 miles (1500 km)	146	Checking the oil level using the dipstick	319	
Wet road surface	172	Checking the oil level using the on-board computer	321	
DVD video		Display message	265	
Operating (on-board computer)	237	Filling capacity	394	
		Notes about oil grades	393	
		Notes on oil level/consumption	319	
E				
EASY-ENTRY feature				
Function/notes	112			
EASY-EXIT feature				
Crash-responsive	113			
Function/notes	112			
EBD (electronic brake force distribution)				
Display message	250			
Function/notes	73			
ECO display				
Function/notes	171			
On-board computer	232			

- Temperature (on-board computer) 245
 - Viscosity 394
 - ESP® (Electronic Stability Program)**
 - AMG menu (on-board computer) ... 245
 - Characteristics 71
 - Deactivating/activating 72
 - Display message 247
 - ETS/4ETS 71
 - Function/notes 71
 - General notes 71
 - Important safety information 71
 - Warning lamp 283
 - ETS/4ETS (Electronic Traction System)** 71
 - Exhaust**
 - see Exhaust pipe
 - Exhaust check** 170
 - Exhaust pipe**
 - Cleaning 331
 - Exterior lighting**
 - Cleaning 329
 - see Lights
 - Exterior mirrors**
 - Adjusting 114
 - Dipping (automatic) 115
 - Folding in/out (automatically) 114
 - Folding in/out (electrically) 114
 - Out of position (troubleshooting) ... 115
 - Setting 114
 - Storing settings (memory function) 117
 - Storing the parking position 115
 - Eyeglasses compartment** 295
- F**
- Features** 298
 - Filler cap**
 - see Fuel filler flap
 - Filling capacities (Technical data)** ... 391
 - Flat tire**
 - Changing a wheel/mounting the spare wheel 377
 - MOExtended tires 337
 - Preparing the vehicle 336
 - TIREFIT kit 338
- G**
- Floormats** 314
 - Front-passenger seat**
 - Adjusting from the driver's seat 104
 - Fuel**
 - Additives 393
 - Consumption statistics 232
 - Displaying the current consumption 231
 - Displaying the range 231
 - Driving tips 170
 - Fuel gauge 31
 - Grade (gasoline) 392
 - Important safety notes 392
 - Problem (malfunction) 166
 - Refueling 163
 - Tank content/reserve fuel 392
 - Fuel filler flap**
 - Opening 164
 - Fuel level**
 - Calling up the range (on-board computer) 231
 - Fuel tank**
 - Capacity 392
 - Problem (malfunction) 166
 - Fuses**
 - Allocation chart 352
 - Before changing 351
 - Dashboard fuse box 351
 - Engine emergency stop 353
 - Fuse box in the engine compartment 352
 - Fuse box in the front-passenger footwell 352
 - Fuse box in the trunk 352
 - Important safety notes 351

- Gear indicator (on-board computer)** 245
- Genuine parts** 21
- Glove box** 295
- H**
- Handbrake**
see Parking brake
- HANDS-FREE ACCESS** 90
- Hazard warning lamps** 122
- Head bags**
Display message 257
- Head restraints**
Adjusting 105
Adjusting (manually) 105
Adjusting (rear) 106
- Head-up display**
Adjusting the brightness 242
Function/notes 229
Important safety notes 229
Setting the position 242
Storing settings (memory function) 117
Switching on or off 229
Switching the display on/off 242
- Headlamps**
Fogging up 125
see Automatic headlamp mode
- Heating**
see Climate control
- High beam flasher** 122
- High-beam headlamps**
Adaptive Highbeam Assist PLUS 123
Display message 261
Switching on/off 122
- Hill start assist** 150
- HOLD function**
Activating 189
Deactivating 189
Display message 271
Function/notes 188
- Hood**
Closing 319
Display message 276
Important safety notes 318
Opening 318
- Horn** 30
- Hydroplaning** 174
- I**
- Ignition lock**
see Key positions
- Immobilizer** 75
- Indicator and warning lamps**
COLLISION PREVENTION ASSIST PLUS 289
- Indicator lamps**
see Warning and indicator lamps
- Indicators**
see Turn signals
- Instrument cluster**
Overview 31
Warning and indicator lamps 32
- Instrument cluster lighting** 33
- Interior lighting**
Control 125
Emergency lighting 126
Overview 125
Reading lamp 125
- J**
- Jack**
Using 379
- Jump starting (engine)** 345
- K**
- Key positions**
SmartKey 147
Start/Stop button 147
- KEYLESS-GO**
Convenience closing feature 95
Deactivation 79
Locking 79
Unlocking 79
- Kickdown**
Driving tips 158
- Knee bag** 50
- L**
- Lamps**
see Warning and indicator lamps

Lane Keeping Assist

see Active Lane Keeping Assist

LATCH-type (ISOFIX) child seat

anchors 63

License plate lamp (display message) 261

Light function, active

Display message 262

Light sensor (display message) 262

Lights

Adaptive Highbeam Assist PLUS 123

Automatic headlamp mode 120

Cornering light function 123

Driving abroad 120

Fogged up headlamps 125

Hazard warning lamps 122

High beam flasher 122

High-beam headlamps 122

Light switch 120

Low-beam headlamps 121

Parking lamps 121

Setting exterior lighting 120

Standing lamps 121

Switching the daytime running

lamps on/off (on-board com-

puter) 243

Switching the spotlight on/off 243

Turn signals 122

see Interior lighting

see Replacing bulbs

Loading guidelines 294

Locking

see Central locking

Locking (doors)

Automatic 86

Emergency locking 87

From inside (central locking but-

ton) 85

Locking centrally

see Central locking

Low-beam headlamps

Display message 260

Setting for driving abroad (sym-

metrical) 120

Switching on/off 121

Lumbar support

Adjusting the 4-way lumbar sup-

port 107

M

M+S tires 358

Magic Body Control 189

MAGIC SKY CONTROL 99

Malfunction message

see Display messages

Matte finish (cleaning instruc-

tions) 328

MBC

see Magic Body Control

mbrace

Call priority 307

Display message 254

Downloading destinations

(COMAND) 307

Downloading routes 310

Emergency call 304

General notes 303

Geo fencing 311

Locating a stolen vehicle 309

MB info call button 306

Remote fault diagnosis 309

Remote vehicle locking 309

Roadside Assistance button 305

Search & Send 308

Self-test 304

Speed alert 310

System 303

Triggering the vehicle alarm 311

Vehicle remote unlocking 308

Mechanical key

Function/notes 81

Inserting 81

Locking vehicle 87

Removing 81

Unlocking the driver's door 86

Media Interface

see Separate operating instructions

Memory card (audio) 236

Memory function

Seats, steering wheel, exterior

mirrors 116

Mercedes-Benz Intelligent Drive

360° camera 207

ABS (Anti-lock Brake System) 66

Active Blind Spot Assist 217

Active Lane Keeping Assist 220

- Active Parking Assist 198
 - ATTENTION ASSIST 211
 - BAS (Brake Assist) 66
 - BAS PLUS (Brake Assist PLUS)
 - with Cross-Traffic Assist 67
 - Crosswind Assist (vehicles with MAGIC BODY CONTROL) 190
 - Crosswind Assist (vehicles without MAGIC BODY CONTROL) 72
 - Cruise control 175
 - DISTRONIC PLUS 177
 - DISTRONIC PLUS with Steering Assist and Stop&Go Pilot 186
 - ESP® (Electronic Stability Program) 71
 - General notes 175
 - MAGIC BODY CONTROL 189
 - Night View Assist Plus 213
 - PARKTRONIC 195
 - PRE-SAFE® (anticipatory occupant protection) 59
 - PRE-SAFE® Brake 73
 - PRE-SAFE® PLUS (anticipatory occupant protection PLUS) 59
 - Rear view camera 203
 - ROAD SURFACE SCAN 192
 - Message memory (on-board computer)** 246
 - Messages**
 - see Display messages
 - see Warning and indicator lamps
 - Mirror turn signal**
 - Cleaning 329
 - Mirrors**
 - see Exterior mirrors
 - see Rear-view mirror
 - see Vanity mirror (in the sun visor)
 - Mobile phone**
 - Menu (on-board computer) 237
 - Modifying the programming (SmartKey)** 80
 - MOExtended tires** 337
 - Mounting wheels**
 - Lowering the vehicle 382
 - Mounting a new wheel 381
 - Preparing the vehicle 378
 - Raising the vehicle 379
 - Removing a wheel 381
 - Securing the vehicle against rolling away 378
 - MP3**
 - Operation 236
 - Multifunction display**
 - Function/notes 228
 - Permanent display 244
 - Multifunction steering wheel**
 - Operating the on-board computer .. 227
 - Overview 33
- N**
- Navigation**
 - Menu (on-board computer) 233
 - Night View Assist Plus**
 - Activating/deactivating 215
 - Cleaning 331
 - Display message 270
 - Function/notes 213
 - Problem (malfunction) 217
 - Switching automatic activation on/off 240
 - Notes on breaking-in a new vehicle** 146
- O**
- Occupant Classification System (OCS)**
 - Conditions 51
 - Faults 56
 - Operation 52
 - System self-test 54
 - Occupant safety**
 - Automatic measures after an accident 60
 - Children in the vehicle 60
 - Important safety notes 43
 - Pets in the vehicle 65
 - PRE-SAFE® (anticipatory occupant protection) 59
 - OCS**
 - Conditions 51
 - Faults 56
 - Operation 52
 - System self-test 54

- Odometer** 231
- Oil**
see Engine oil
- On-board computer**
AMG menu 245
Assistance graphic menu 239
Assistance menu 240
Display messages 246
Displaying a service message 324
DISTRONIC PLUS 183
Factory settings 244
Head-up display 229
Important safety notes 226
Instrument cluster menu 243
Lights menu 243
Media menu 236
Menu overview 231
Message memory 246
Navigation menu 233
Operation 227
Radio menu 235
Service menu 239
Settings menu 239
Standard display 231
Telephone menu 237
Trip menu 231
Video DVD operation 237
- Operating safety**
Declaration of conformity 25
Important safety notes 24
- Operating system**
see On-board computer
- Operator's Manual**
Overview 22
Vehicle equipment 22
- Outside temperature display** 227
- Overhead control panel** 37
- P**
- Paint code number** 390
- Paintwork (cleaning instructions)** ... 327
- Panic alarm** 42
- Panorama roof** 97
- Parcel net hooks** 297
- Parking**
Important safety notes 166
Parking brake 168
Position of exterior mirror, front-passenger side 115
Rear view camera 203
see PARKTRONIC
- Parking aid**
Active Parking Assist 198
see Exterior mirrors
see PARKTRONIC
- Parking assistance**
see PARKTRONIC
- Parking brake**
Display message 250
Electric parking brake 168
Warning lamp 285
- Parking lamps**
Switching on/off 121
- PARKTRONIC**
Deactivating/activating 197
Driving system 195
Function/notes 195
Important safety notes 195
Problem (malfunction) 198
Range of the sensors 195
Warning display 196
- PASSENGER AIR BAG**
Indicator lamps 43
- PASSENGER AIR BAG indicator lamp**
Problem (malfunction) 259
- Perfume atomizer**
Operating 140
Perfume vial 140
Problem (malfunction) 142
- Pets in the vehicle** 65
- Plastic trim (cleaning instructions)** 332
- Power locks** 86
- Power washers** 327
- Power windows**
see Side windows
- PRE-SAFE® (anticipatory occupant protection)**
Display message 254
Operation 59
- PRE-SAFE® Brake**
Activating/deactivating 241
Display message 255

- Function/notes 73
 - Important safety notes 73
 - Warning lamp 289
 - PRE-SAFE® PLUS (anticipatory occupant protection PLUS)**
 - Operation 59
 - Program selector button** 158
 - Protection against theft**
 - ATA (Anti-Theft Alarm system) 76
 - Immobilizer 75
 - Protection of the environment**
 - General notes 21
 - Pulling away**
 - Automatic transmission 150
 - General notes 150
 - Hill start assist 150
- Q**
- QR code**
 - Rescue card 27
 - Qualified specialist workshop** 25
- R**
- Radio**
 - Selecting a station 235
 - Radio-wave reception/transmission in the vehicle**
 - Declaration of conformity 25
 - Reading lamp** 125
 - Rear compartment**
 - Setting the air vents 143
 - Stowage compartment 296
 - Rear lamps**
 - see Lights
 - Rear seats**
 - Overview 39
 - Rear view camera**
 - Cleaning instructions 330
 - Function/notes 203
 - Switching on/off 204
 - Rear window blind** 300
 - Rear window defroster**
 - Problem (malfunction) 139
 - Switching on/off 138
 - Rear-view mirror**
 - Anti-glare (manual) 113
 - Dipping (automatic) 115
 - Recuperation display** 231
 - Refrigerant (air-conditioning system)**
 - Important safety notes 396
 - Refueling**
 - Fuel gauge 31
 - Important safety notes 163
 - Refueling process 164
 - see Fuel
 - Remote control**
 - Garage door opener 311
 - Programming (garage door opener) 312
 - Replacing bulbs**
 - General notes 126
 - Reporting safety defects** 26
 - Rescue card** 27
 - Reserve (fuel tank)**
 - see Fuel
 - Reserve fuel**
 - Display message 266
 - Warning lamp 286
 - Residual heat (climate control)** 139
 - Restraint system**
 - Display message 256
 - Introduction 42
 - Warning lamp 285
 - Warning lamp (function) 43
 - Reversing feature**
 - Roller sunblind 97
 - Side windows 94
 - Trunk lid 88
 - Reversing lamps (display message)** 262
 - ROAD SURFACE SCAN** 192
 - Roadside Assistance (breakdown)** 23
 - Roller sunblind**
 - Panorama roof 97
 - Rear window 300
 - Roller sunblind for the panorama roof**
 - Opening and closing 98
 - Operating 97
 - Resetting 98
 - Roof lining and carpets (cleaning guidelines)** 333

Roof load (maximum) 397

S

Safety

Occupant Classification System (OCS) 51
see Operating safety

Safety system

see Driving safety systems

Seat belts

Adjusting the driver's and front-passenger seat belt 47
Cleaning 333
Correct usage 45
Fastening 46
Important safety guidelines 44
Introduction 44
Releasing 47
Warning lamp 279
Warning lamp (function) 48

Seating

Seating comfort package 107

Seating comfort package 107

Seats

Active multicontour seat 107
Adjusting (electrically) 104
Adjusting the 4-way lumbar support 107
Adjusting the head restraint 105
Cleaning the cover 332
Correct driver's seat position 102
EASY-ENTRY/EXIT system 112
Folding the backrests forward/back 106
Important safety notes 103
Seat backrest display message 276
Seat heating 107
Seat heating problem 109
Seat ventilation 109
Seat ventilation problem 110
Storing settings (memory function) 117
Switching seat heating on/off 107
Switching seat ventilation on/off .. 109

Section

Wheels and tires 356

Selector lever

Cleaning 332
see Automatic transmission

Sensors (cleaning instructions) 329

Service menu (on-board computer) 239

Service products

Brake fluid 394
Coolant (engine) 395
Engine oil 393
Fuel 392
Important safety notes 391
Refrigerant (air-conditioning system) 396
Washer fluid 396

Settings

Factory (on-board computer) 244
On-board computer 239

SETUP (on-board computer) 245

Side impact air bag 50

Side marker lamp (display message) 262

Side windows

Cleaning 329
Convenience closing feature 95
Convenience opening feature 95
Important safety information 93
Opening/closing 94
Problem (malfunction) 97
Resetting 96

SmartKey

Changing the battery 82
Changing the programming 80
Checking the battery 82
Convenience closing feature 95
Convenience opening feature 95
Display message 277
Door central locking/unlocking 79
Important safety notes 78
KEYLESS-GO start function 80
Loss 83
Mechanical key 81
Overview 78
Positions (ignition lock) 147
Problem (malfunction) 83
Starting the engine 150

Snow chains 359

- Sockets**
 Center console 301
 General notes 301
 Rear compartment 301
 Trunk 302
- Special seat belt retractor** 61
- Specialist workshop** 25
- Speed, controlling**
 see Cruise control
- Speedometer**
 Activating/deactivating the additional speedometer 244
 Digital 232
 In the Instrument cluster 31
 Selecting the unit of measurement 243
 see Instrument cluster
- Standing lamps**
 Display message 262
 Switching on/off 121
- Start/Stop button**
 Removing 149
 Starting the engine 150
- Start/stop function**
 see ECO start/stop function
- Starting (engine)** 149
- STEER CONTROL** 75
- Steering**
 Warning lamps 291
- Steering (display message)** 276
- Steering Assist and Stop&Go Pilot (DISTRONIC PLUS)**
 Display message 272
- Steering assistant STEER CONTROL**
 see STEER CONTROL
- Steering wheel**
 Adjusting (electrically) 110
 Button overview 33
 Buttons (on-board computer) 227
 Cleaning 332
 EASY ENTRY/EXIT feature 112
 Important safety notes 110
 Paddle shifters 159
 Steering wheel heating 111
 Storing settings (memory function) 117
- Steering wheel heating**
 Problem (malfunction) 112
 Switching on/off 111
- Steering wheel paddle shifters** 159
- Stowage areas** 294
- Stowage compartments**
 Armrest (under) 296
 Center console 295
 Center console in rear compartment 297
 Cup holders 298
 Door 296
 Eyeglasses compartment 295
 Glove box 295
 Important safety information 294
 Rear 296
 Rear seat backrest 297
 Stowage net 297
 Under driver's seat/front-passenger seat 296
- Stowage net** 297
- Stowage space**
 Parcel net retainers 297
 Securing a load 297
- Stowage well beneath the trunk floor** 297
- Summer tires**
 In winter 358
- Sun visor** 299
- Suspension tuning**
 Active Body Control ABC 191
 AIRMATIC 193
 SETUP (on-board computer) 245
- Switching air-recirculation mode on/off** 139

T

- Tachometer** 226
- Tail lamps**
 Display message 261
 see Lights
- Tank content**
 Fuel gauge 31
- Technical data**
 Capacities 391
 Information 390
 Tires/wheels 382

- Vehicle data 397
- Telephone**
- Accepting a call (multifunction steering wheel) 238
- Display message 277
- Introduction 237
- Menu (on-board computer) 237
- Number from the phone book 238
- Redialing 238
- Rejecting/ending a call 238
- Temperature**
- Coolant 226
- Engine oil (on-board computer) 245
- Outside temperature 227
- Setting (climate control) 136
- Tire pressure**
- Calling up (on-board computer) 363
- Checking manually 362
- Display message 273
- Important safety notes 363
- Maximum 362
- Not reached (TIREFIT) 339
- Notes 361
- Reached (TIREFIT) 340
- Recommended 359
- Tire pressure monitor**
- Checking the tire pressure electronically 364
- Function/notes 363
- General notes 363
- Important safety notes 363
- Radio type approval for the tire pressure monitor 366
- Restarting 365
- Warning lamp 290
- Warning message 365
- TIREFIT kit** 338
- Tires**
- Aspect ratio (definition) 376
- Average weight of the vehicle occupants (definition) 375
- Bar (definition) 375
- Changing a wheel 377
- Characteristics 375
- Checking 357
- Curb weight (definition) 376
- Definition of terms 375
- Direction of rotation 378
- Display message 273
- Distribution of the vehicle occupants (definition) 377
- DOT (Department of Transportation) (definition) 375
- DOT, Tire Identification Number (TIN) 374
- GAWR (Gross Axle Weight Rating) (definition) 375
- GVW (Gross Vehicle Weight) (definition) 376
- GVWR (Gross Vehicle Weight Rating) (definition) 376
- Important safety notes 356
- Increased vehicle weight due to optional equipment (definition) 375
- Kilopascal (kPa) (definition) 376
- Labeling (overview) 371
- Load bearing index (definition) 377
- Load index 374
- Load index (definition) 376
- Maximum load on a tire (definition) 376
- Maximum loaded vehicle weight (definition) 376
- Maximum permissible tire pressure (definition) 376
- Maximum tire load 374
- Maximum tire load (definition) 376
- MOExtended tires 358
- Optional equipment weight (definition) 377
- PSI (pounds per square inch) (definition) 376
- Replacing 377
- Service life 358
- Sidewall (definition) 377
- Speed rating (definition) 376
- Storing 378
- Structure and characteristics (definition) 375
- Summer tires in winter 358
- Temperature 371
- TIN (Tire Identification Number) (definition) 377
- Tire bead (definition) 377
- Tire pressure (definition) 376
- Tire pressures (recommended) 375